







SECTION A

CODABAR

* Enable Codabar




* Disable Codabar

Enable
Dual Field Codabar* Disable
Dual Field CodabarEnable
Tab in Dual Codabar* Disable
Tab in Dual Codabar

This feature requires *Dual Field Codabar* to be enabled. The scanner will insert a tab between the fields of the dual field Codabar.

Transmit Codabar Start/Stop Characters




Transmits Codabar's start/stop characters before and after each bar code.

* Do Not Transmit Codabar Start/Stop



Will not transmit Codabar's start/stop characters before and after each bar code.

Convert Codabar Start/Stop Characters to Lowercase



* Do Not Convert Codabar Start/Stop Characters to Lowercase

